








#### **REGULAR BRICKS**




#### STAX




1-1









1-2







1-3









1-4







1-5









1-6







1-7










1-8














1-10















# 1-12















1-14














1-16






1-17










1-18















1-20














1-22














## 1-24







1-25










1-26














1-28












1-30









#### Special instructions:

- 1. To replace the CR2032 button cell battery, please see the 4x4 Motion Activated Power STAX Instruction manual.
- 2. As an upgrade, to avoid using batteries, we recommend replacing the button cell Power STAX with the rechargeable 4x4 Mobile Power STAX (Item# S-11503). You can purchase this from your STAX retailer or directly through our webshop at www.lightstax.eu!